

# Vantage PRO2™ INSTALLATION DIAGRAM

## Transmitting to a Vantage Pro2™ Console and Weather Envoy™ simultaneously

This diagram shows a Vantage Pro2 sensor suite wirelessly connected to both a Vantage Pro2 console and Weather Envoy, which is connected to a computer via a WeatherLink data logger. The transmission distance between a sensor suite and Envoy or console is up to 1000' (300 m) line-of-sight, or up to 600' (180 m) through walls and other obstructions. The cable distance between an Envoy and a computer is 8' (2.4 m) using a USB connection. Multiple receivers (both Envoy and consoles) can "listen" to the same station or set of stations.

