

# Vantage PRO<sup>2</sup>™ INSTALLATION DIAGRAM

## Vantage Connect™ Moving Data to Computer and Smartphone

This diagram shows a Vantage Pro2 sensor suite sending data to a Vantage Connect. The Vantage Connect then transmits the data via cellular connection to WeatherLink.com, where it can be viewed on a computer or smartphone. The transmission distance between a sensor suite and Vantage Connect is up to 1000' (300 m) line-of-sight, or up to 600' (180 m) through walls and other obstructions.

